

Starting Up Your New Pool – 17,500 gallons



Starting Up Your Pool (XStream™ Filter System)

IF POSSIBLE, BRING IN A SAMPLE OF YOUR TAP WATER (ABOUT 2 CUPS) TO HAVE TESTED **BEFORE ADDING** ANY CHEMICALS. IF YOU HAVE METALS SUCH AS IRON, COPPER OR MANGENESE IN YOUR WATER OR YOU HAVE WELL WATER YOU **MUST** ADD POOL MAGNET BEFORE ADDING ANY CHLORINE! FAILURE TO DO SO MAY RESULT IN DISCOLORATION OF YOUR POOL WATER AND/OR STAINING OF YOUR LINER. (THIS IS NOT COVERED UNDER MANUFACTURER WARANTY.)

1. **PLEASE FOLLOW THE STEPS BELOW** WHEN STARTING YOUR FILTER FOR THE FIRST TIME:
 - A. CLOSE DRAIN VALVE AT THE BASE OF THE FILTER TANK.
 - B. SECURE AND LOCK EASY-LOK™ RING.
 - C. OPEN AIR RELIEVE VALVE (TURN LEVER TO LEFT)
 - D. OPEN ANY VALVES (OPTIONAL SHUT-OFF VALVES ON THE PUMP OR TANK)
 - E. ONCE AIR HAS ESCAPED THE FILTER AND A STEADY STREAM OF WATER IS FLOWING FROM THE AIR RELIEF VALVE, CLOSE THE AIR RELIEF VALVE AND NOTE THE PRESSURE GAUGE READING.

NOTE: ALWAYS **TURN OFF THE PUMP** WHENEVER YOU MOVE THE FILTER HANDLE ON YOUR VALVE.

2. IF YOU PURCHASED THE OPTIONAL NATURE 2 CARTRIDGE THAT FITS DOWN THE CENTER OF YOUR PLEATED FILTER CARTRIDGE, BE SURE TO BALANCE YOUR PH AND ALKALINITY TO THEIR PROPER LEVELS BEFORE INSERTING THE NATURE 2 CARTRIDGE.
3. WITH THE PUMP RUNNING ADD AN INITIAL DOSE OF **BACK-UP ALGAECIDE** (26 OUNCES) DIRECTLY INTO THE POOL IN FRONT OF YOUR WATER RETURN FITTING. THIS DISTRUBUTES THE WATER FASTER AND MORE EVENLY INTO THE POOL. (YOU SHOULD **NEVER** ADD CHEMICALS THROUGH THE SKIMMER WITH THE EXCEPTION OF **STABILIZER 100***.)
4. PLACE 2 **SMART STICKS** IN YOUR SKIMMER BASKET (IF YOU HAVE A LOT OF LEAVES/BUGS ASK US ABOUT A **SKIM-MOR** FOR YOUR SKIMMER BASKET)
5. "SHOCK" YOUR POOL WITH 2 POUNDS OF **EASY SHOCK & SWIM**

*TO **SAVE** MONEY ON CHLORINE – AN **OPTIONAL** CHEMICAL IS AVAILABLE AND SHOULD BE ADDED AT THE BEGINNING OF EVERY SEASON. FOR YOUR SIZE POOL YOU WILL NEED TO ADD 5 POUNDS OF **STABILIZER 100**. **ADD VERY SLOWLY** THROUGH THE SKIMMER WITH THE PUMP RUNNING. **DO NOT** CLEAN THE FILTER FOR 48 HOURS AS THE STABILIZER SLOWLY DISSOLVES INSIDE OF YOUR FILTER SYSTEM.

Maintaining Your New Pool – 17,500 gallons



Weekly

STEP #1

- USE **SMART STICKS** TO MAINTAIN 1.0 PPM CHLORINE RESIDUAL. REPLENISH THE SMART STICK IN YOUR SKIMMER APPROXIMATELY ONCE A WEEK.

STEP #2

- ADD 2 LBS OF **EASY SHOCK & SWIM** TO ELIMINATE UNDESIRABLE COMPOUNDS
 - ADD WITH THE PUMP RUNNING. DO NOT SWIM UNTIL THE SANITIZER RESIDUAL RETURNS TO THE IDEAL RANGE.

STEP #3

- ADD 4 oz OF **BACK UP** TO PREVENT ALGAE GROWTH
 - ADD **BACK UP** WEEKLY AS PART OF YOUR ONCE-A-WEEK 3 STEP PROGRAM. BACK UP IS SPECIALLY FORMULATED TO WORK WITH SMART STICKS AND EASY SHOCK & SWIM TO PREVENT ALGAE. ADD WITH THE PUMP RUNNING.
- TWICE A WEEK, TEST AND MAINTAIN pH 7.4 - 7.6
 - IF pH IS HIGH, ADD **LO 'N SLO**. IF pH IS LOW, ADD **BALANCE PAK 200** ACCORDING TO DIRECTIONS FOR THE GALLONS IN YOUR POOL.

SEASON USAGE

FOR 12,500 GALLON POOL FOR 16 WEEKS

16 lbs of **Smart Sticks**

32 lbs of **Easy Shock & Swim**

3 qts of **Back UP**

Tips

- ❖ RUN PUMP A MINIMUM OF **12 HOURS** EVERY DAY. RUNNING THE PUMP 24/7 IS LESS STRESS ON THE PUMP THAN CONSTANTLY TURNING IT ON/OFF. IT IS ALSO BENEFICIAL FOR THE POOL WATER CLAIRTY. THE COST FOR ELECTRICITY CAN BE OFFSET BY THE **SAVINGS** IN POOL CHEMICALS BY KEEPING THE WATER MOVING AND THE FILTER FILTERING.
- ❖ BRUSH AND VACUUM POOL TO KEEP THE SURFACE CLEAN AND FREE OF DIRT AND DEBRIS. BE SURE TO EMPTY PUMP AND SKIMMER BASKETS AS NEEDED. *THIS IS IMPORTANT, AS IT ALLOWS ADEQUATE WATER FLOW THROUGH THE FILTRATION SYSTEM.* IF FLOW IS OBSTRUCTED BY LEAVES/DEBRIS IT WILL CAUSE STRAIN ON YOUR PUMP.
- ❖ TAKE YOUR SOLAR COVER OFF EVERY FEW DAYS TO ALLOW THE POOL TO BREATHE IF IT IS NOT BEING USED.
- ❖ HAVE YOUR WATER TESTED BY POOL WORKS MIDWAY THROUGH THE SUMMER. BE SURE TO BRING IN AN INVENTORY OF ALL THE CHEMICALS YOU HAVE AT HOME.
- ❖ TO HELP PREVENT DETERIORATION OF YOUR SOLAR COVER BE SURE TO REMOVE IT WHEN CHLORINE LEVELS ARE HIGH (WHEN SHOCKING). COVER IT WITH THE PROTECTIVE PLASTIC SHEET WHEN TAKEN OFF OF THE POOL AND LEFT IN THE SUNSHINE.
- ❖ REPLACE YOUR NATURE² MINERAL CARTRIDGE **EVERY** SPRING. REPLACE FILTER SAND EVERY 3 TO 5 YEARS.
- ❖ STORE ALL CHEMICALS AND TEST KITS IN A COOL, DRY AREA AND OUT OF THE REACH OF CHILDREN & PETS.
- ❖ **NEVER** MIX CHEMICALS TOGETHER – ALWAYS ADD YOUR CHEMICALS TO WATER – **NOT** WATER TO CHEMICALS.
- ❖ VACUUM ON THE “**WASTE**” POSITION WHEN CLEANING UP LEAVES, LARGE DEBRIS OR ALGAE. THIS ALLOWS THE WATER TO BYPASS THE FILTER AND GO DIRECTLY OUT THE BACKWASH LINE. FOR NORMAL DIRT AND SAND YOU CAN VACUUM ON “FILTER” POSITION. **NEVER** VACUUM ON THE **BACKWASH** POSITION.
- ❖ ADD **STABILIZER 100** EVERY SPRING AT START-UP.

