

Britt Seat Installation Instructions

1. Place seat on the bike with the front tab under the stay.
2. Press seat firmly forward and center the rear of the seat on the fender and mark the hole in the mounting tab of the seat on the fender.
3. Drill a 3/8" hole (using a center punch will aid in this process) and insert the hollow-tapped 3/8" -16 bolt through the hole and put on the Ny-lock nut, and tighten to 10 Ft.Lb. (trim any excess under fender if desired)
4. Place seat on the bike and install the 1/4"-28 button-head bolt through the tab and into the hollow-tapped bolt and tighten to 10 Ft. Lb.

**BRITT MOTORSPORTS, INC.
6431 MARKET ST
WILMINGTON, NC 28405
Phone: (910) 791-8321
www.brittmotorsports.com**