



- * Use cable ties to secure all harness' to frame structure, keep away from exhaust pipes, coolant tubes, and turning shafts.
- * 00-1133, flood light harness - long lead out to driver side, short lead out to passenger side.
- * 00-1134, power harness - End w/60 amp fuse attaches to power panel. 00-1130, power panel w/harness mounts under passenger seat.
- * 00-1131, cab harness - follows back panel seam to passenger side roll cage, down roll tube between seat back supports and back panel, down over seat frame.
- * 00-1132, rear harness - connects brake lights and (2) spade connectors to power panel. Brake light connection and spade connections are on drivers side, crosses over engine to power panel.